


Instructions for the heatsink: For the maximum power you need to add extra heatsink to the aluminium block. The size is depending on the ambient temperature and the air ventilation. For details check the datasheet.



Title		
Standard potentiometer or throttle + brake pot		
Size	Number	Revision
A3	HL5020 v1.06	Rev1
Date:	2022.03.14.	Sheet of
File:	E:\Projekte\...\Wir1.SchDoc	Drawn By: